

2016 Nautique Dealer Service School Manual

TABLE OF CONTENTS

Section 1 - G Series

- 1.01 G23, G25 MAIN HARNESS
- 1.02 G21 HULL & DECK HARNESS
- 1.03 G SERIES WIRE SCHEMATICS
- 1.04 BALLAST VALVE ACTUATOR HARNESS - DIODE BLOCK TYPE 1
- 1.05 BALLAST VALVE ACTUATOR HARNESS - DIODE BLOCK TYPE 2
- 1.06 BVA Fuse Adapter
- 1.07 CAN 2 Surf Select harness_DTM version
- 1.08 CAN NETWORK CONNECTOR - NO LANYARD
- 1.09 HEATER w Deutsch
- 1.10 Heated Passenger Seat - G Series
- 1.11 Standard BREAKER PANEL (210, 230, G21, G23, G25)
- 1.12 M Series Studio Elite BREAKER PANEL (G21, G23, G25)
- 1.13 LINC Video, USB, Polk Stereo Remote Harness for 2016 G Series
- 1.14 SHIFT OVERRIDE SWITCH
- 1.15 Stereo Layouts G Series
 - 1.15.01 M SERIES ELITE G21
 - 1.15.02 M SERIES ELITE G23 G25
 - 1.15.03 M SERIES STUDIO ELITE WITH DASH TWEETERS G21
 - 1.15.04 M SERIES STUDIO ELITE WITH JL WAVEFRONT G23 G25
 - 1.15.05 Nautique zone control RCA connections
 - 1.15.06 M Series Elite no tower speakers_Amp Board
 - 1.15.07 M Series Elite no tower speakers_Amp Settings
 - 1.15.08 M Series Elite plus 7.7 tower speakers_Amp Board
 - 1.15.09 M Series Elite plus 7.7 tower speakers_Amp Settings
 - 1.15.10 M Series Elite plus 8.8 tower speakers_Amp Board
 - 1.15.11 M Series Elite plus 8.8 tower speakers_Amp Settings
 - 1.15.12 M Series Studio Elite no tower speakers_Amp Board
 - 1.15.13 M Series Studio Elite no tower speakers_Amp Settings
 - 1.15.14 M Series Studio Elite plus 7.7 tower speakers_Amp Board
 - 1.15.15 M Series Studio Elite plus 7.7 tower speakers_Amp Settings
 - 1.15.16 M Series Studio Elite plus 8.8 tower speakers_Amp Board
 - 1.15.17 M Series Studio Elite plus 8.8 tower speakers_Amp Settings

Section 2 – 210 & 230

- 2.01 210-230 MAIN HARNESS
- 2.02 Standard BREAKER PANEL (210, 230, G21, G23, G25)
- 2.03 HEATER w Deutsch
- 2.04 Heated Passenger Seat - 210 & 230
- 2.05 CAN 2 Surf Select harness_DTM version
- 2.06 CAN NETWORK CONNECTOR - NO LANYARD
- 2.07 SHIFT OVERRIDE SWITCH
- 2.08 Throttle and Shifter 210 & 230
- 2.09 Stereo Layouts 210 & 230
 - 2.09.01 MX Series plus tower speakers_Amp Board
 - 2.09.02 MX Series plus tower speakers_Amp Settings
 - 2.09.03 MX Series Premier no tower speakers_Amp Board
 - 2.09.04 MX Series Premier no tower speakers_Amp Settings
 - 2.09.05 MX Series Premier plus tower speakers_Amp Board
 - 2.09.06 MX Series Premier plus tower speakers_Amp Settings
 - 2.09.07 MX SERIES PREMIER SKI200 SPORT200 210 230
 - 2.09.08 MX SERIES WITH LINC SKI200 SPORT200 210 230
 - 2.09.09 STEREO CONNECTOR
 - 2.09.10 TOWER SPEAKERS AMP HARNESS
 - 2.09.11 BOAT SPEAKERS AMP HARNESS

Section 3 - Ski & Sport 200

- 3.01 2016 SKI200 MAIN HARNESS
- 3.02 2016 SPORT200 MAIN HARNESS
- 3.03 DUAL PDM BREAKER PANEL (2015-2016)
- 3.04 SINGLE PDM BREAKER PANEL (2015-2016)
- 3.05 CAN NETWORK CONNECTOR - NO LANYARD
- 3.06 SHIFT OVERRIDE SWITCH
- 3.07 HEATER w Deutsch
- 3.08 2016 BASE (NO LINC) SKI & SPORT200 DRIVER SEAT HEATER HARNESS
- 3.09 2016 LINC SKI & SPORT200 DRIVER SEAT HEATER HARNESS
- 3.10 Heated Passenger Seat - Ski and Sport 200
- 3.11 Stereo Layouts Ski and Sport 200
 - 3.11.01 2016 MX SERIES PREMIER SKI200 SPORT200 210 230
 - 3.11.02 2016 MX SERIES WITH LINC SKI200 SPORT200 210 230
 - 3.11.03 MX Series plus tower speakers_200_Amp Board
 - 3.11.04 MX Series plus tower speakers_200_Amp Settings
 - 3.11.05 MX Series Premier no tower speakers_200_Amp Board
 - 3.11.06 MX Series Premier no tower speakers_200_Amp Settings
 - 3.11.07 MX Series Premier no tower speakers_200CB_Amp Board
 - 3.11.08 MX Series Premier no tower speakers_200CB_Amp Settings
 - 3.11.09 MX Series Premier plus tower speakers_200_Amp Board
 - 3.11.10 MX Series Premier plus tower speakers_200_Amp Settings
 - 3.11.11 MX Series Premier plus tower speakers_200CB_Amp Board
 - 3.11.12 MX Series Premier plus tower speakers_200CB_Amp Settings

Section 4 - PCM

- 4.01 2016 Generation 5 V8 Engine Service Manual
- 4.02 2016 Generation 4 V8 Engine Service Manual
- 4.03 Direct Injection Engine Maintenance Manual
- 4.04 GCP_4G Diagnostic Manual
- 4.05 Direct Injection Engine Parts Manual

Section 5 - Presentations and Miscellaneous

- 5.01 2016 Electrical Presentation - Dusty Abel
- 5.02 2016 LINC Presentation - Andrew Cochrum
- 5.03 2016 Stereo Layout Drawings - All Models
- 5.04 2012-2015 Electrical Presentation - Larry Shea
- 5.05 JL Audio Presentation